

CRYSTAL DUST COLLECTOR

"MINI" and "NORMAL"

- Built-in - MANUAL GUIDE

PLEASE READ ALL THE SAFETY INSTRUCTIONS BEFORE THE DEVICE OPERATION. KEEP THE MANUAL GUIDE SAFE FOR FUTURE REFERENCE.

Product introduction:

The CRYSTAL "MINI" and "NORMAL" Built-in Dust Collectors are used for the emerging dust/contaminations continues absorbing from the nail sculpting- and the manicure procedure.

SPECIFICATIONS

CRYSTAL DUST COLLECTOR "MINI"
Voltage: DC 12V~
Power: max. 5.4W
Air Flow: max. 183.8 m³/h
Noise level: 44.5dBA
Weight (g): 475g
Measure (mm): 170*170*60mm

CRYSTAL DUST COLLECTOR "NORMAL"
Voltage: DC 12V~
Power: max. 5.4W
Air Flow: max. 183.8 m³/h
Noise level: 44.5dBA
Weight (g): 581g
Measure (mm): 290*170*60 mm

AC ADAPTER:
Input: AC 100-240V~, 50/60Hz
Output: DC 12V~

ACCESSORIES:
- 1pc AC Adapter
- 1pc Dust Bag with Filter

OPERATION

ATTENTION! Before the machine operation, check the device and its accessories just state.

1. Unpack the device and the accessories from the packaging.
2. Choose a suitable place for the device built in and usage.
3. After the device setting connect the adapter and the power cable together, than plug it into the device than to the outlet.
4. Turn on the device with the switcher I/O (ON/OFF) on the back of the machine. The device will run on continuous mode.
5. Place the hand above the exhaust vent opening, than you can start working with it.

ATTENTION! DO NOT allow any kind of irrelevant object to the exhaust vent opening (nails, nail form, file...etc.)!

6. After the work is finished with the device, turn it off with the I/O (ON/OFF) switcher at the back of the machine than pull out the adapter from the device and from the outlet as well.

CLEANING AND STORAGE

ATTENTION! Before cleaning always anneal the device (turn off the machine, than remove the assembled adapter from the machine and from to the AC outlet as well), as well as wait for the machine full stop. DO NOT disassemble the device!! The CRYSTAL "MINI" and "NORMAL" Dust Collectors cleaning/maintenance are identical. For the cleaning, use compressed air, brush and a non synthetic soft towel.

DEVICE: Take out the built-in device from its place, than put it into an even surfaced stable place (it is recommended to put a cloth under the device). Turn the device upside down (the dust bag has to be facing up) than move off the dust bag and the filter with care (see Dust bag and Filter chapter). Clean the external panel and the fan blades through the security grids with the brush and the compressed air. For the hard to reach parts (switcher, adapter socket, joints) use compressed air. If the device cleaning is finished, put back the fully dry dust bag and filter to the back of the exhaust vent, after that place back the device to its preconceived place.

NOTICE: If it necessary the device external panel can be cleaned with a lightly moist, soft cloth, but pay attention that the device CANNOT have any liquid inside in it or in its switcher, openings or sockets, as well as CANNOT be contacted with the device adapter or power cord. After the moist cleaning, always wait for the device full dry as well as do not put it under it charge at least 1-2 min.! DO NOT use solvent detergents!

ACCESSORIES: Pull out the power cable from the adapter, than clean both of them with brush and compressed air. Pay high priority of the sockets and joints.

In case of average frequency use, clean the device and its accessories according to the described above at least once a week.

DUST BAG AND FILTER: Take out the built-in device from its place, than put it into an even surfaced stable place (it is recommended to put a cloth under the device). Turn the device upside down (the dust bag has to be facing up) than move off the dust bag and the filter with care. Turn out the filter and the dust bag than empty the accumulated dust/contaminations. Clean the emptied dust bag and filter with careful hand wash in lukewarm, lightly detergent water. After the cleaning wait for the dust bag and the filter full dry. Place them back to the exhaust vent only after the full dry.

The emptying itself NOT enough for the dust bag and the filter cleaning! Wash out the dust bag and the filter according to the described above after each of the emptying. Use the device only with full dry dust bag and filter!

If you notice lower capacity during in use or the device has less downdraught, check the dust bag saturation and if it is reasonable clean it according to the described above (see **DUST BAG AND FILTER CHAPTER**).

In case of average frequency use, check the dust bag saturation at least once a week and if it is reasonable clean it according to the described above (see **DUST BAG AND FILTER CHAPTER**).

For future information about the device cleaning/maintenance visit our website: <http://www.nails.tv> or if it requires look for the place of purchase.

STORAGE: Always store the device and its accessories in a dry place, far from radiant heat in a clean state.

Before the device installation always check the device and its accessories for any kind of defect.

SAFETY CAUTIONS

1. Only for indoor use, between 0-40°C (32-104°F)!
2. The machine cannot be left behind, without supervision when it is turned on.
3. Do not put the machine onto places where it can be knocked down, or may fall off. Use the device only in stable, even surfaced places!
4. The machine CANNOT have any liquid inside in it or in its switcher, openings or sockets, as well as CANNOT be contacted with the device adapter or the power cord.
7. Do not ever touch the machine or its accessories with moist/wet hand!
5. DO NOT ever activate the machine if its power cord or adapter or socket is damaged, as well as if it had any kind of accident or it fell into the water!
8. Take the device to the place of purchase for examination and repair.
6. DO NOT allow any kind of irrelevant object to the device openings, sockets as well as to the exhaust vent opening (nails, nail form, file...etc.)!
7. Use/store the device only in dry places and keep it far from radiant heat! Avoid damp, wet places!
8. Use the device only with the original accessories.
9. The electric parts of the machine may have electric pressures within them even when the device is turned off.
10. At the end of the device use, always anneal the machine (turn off the device, than remove the assembled adapter from the machine than from to the AC outlet as well).

For more information about the device, visit our website: <http://www.crystalnails.com> or look for the place of purchase.

NOTICE!

If any case of malfunction was found or any parts of the machine has to be replaced or repaired, please contact with to the dealer where the unit was purchased!

Importer: Elite Cosmetix LTD.; Jozsef Krt. 44., H-1085 Budapest, Hungary