

PARAFFIN MACHINE

MANUAL GUIDE

BEFORE THE DEVICE USE READ ALL THE SAFETY INSTRUCTIONS WITH ATTENTION. KEEP THIS MANUAL GUIDE SAFE FOR FUTURE REFERENCE.

INTRODUCTION:

The PARAFFIN MACHINE is used for the solid paraffin melting and heating for the professional hand- & feet care process.

SPECIFICATION:

Input: AC 220-240V; 50Hz
Amperage: 0.5A
Weight: 1480g
Measure: 325*235*180mm

OPERATION

Before the device use always check device and its accessories just state.

1. Unpack the device and its accessories from the packaging, than select and even surfaced, stable place for the device use.
2. Lift the lid than take out the accessories from the container bin, than wipe it out with a soft cloth.
3. Place back the safety grid into the bin bottom, than place in the necessary amount paraffin into the container bin. Pay attention not to exceed the max. 2 Liter amount (2000ml). It is recommended to add the paraffin's in portions to the bin.
4. Connect the device power cord into the outlet. The device indicator light will turn on with a green light.
5. Place back the lid, than set the front switcher into „H” position (High level = 70°C), when the paraffin is melted at least 70-75%, set back the switcher into „M” position (Medium level = app. 40°C). See more below at the **USAGE** chapter.
6. If you do not wish to use the device for a time being, set the front switcher into „L” position (Low level = it is used to keep the paraffin in a warm liquid state in low heat).
7. Adjust the heat if you feel the paraffin temperature too low or too high.
8. After the device use is finished, set the front switcher to „OFF” position, than remove the device power cord from the outlet.

ATTENTION!

The max. 70°C temperature („H” position) is not suitable for customer use. It is only used to start the paraffin melting process. It is recommended to start the melting process at 70°C („H”), than after 4-5min. when the paraffin app. 70-75% is melted set back the temperature to 40°C („M” position) Notice: the melting time and temperature can be different with the different type of paraffin's. If you notice the paraffin top is started to solidify or “skinning” raise the temperature with a few degree and if it is necessary stir the paraffin in the bin.

USAGE (on customer):

1. Before every customer use always check the paraffin correct temperature and always make sure of the customer proper skin and nail health.
2. Remove all accessories from the customer hand/feet, than disinfect the customer limbs.
3. Apply suitable skin scrub for the customer skin surface, than when the process finished remove all the applied material from the skin surface, than wipe it dry.
4. Apply suitable nourishing cream into the customer hand/feet, than place the customer limbs into the container bin bottom. **Attention!** Before the customer use always check the paraffin correct temperature.
5. Take out the customer hand/feet from the paraffin, than wait for at least 10sec till the paraffin solidifies on the skin.
6. Repeat the previous step a few times (**USAGE 4. chapter**) than place the customer limbs separately into a waterproof foil or wrap. If it is necessary place the customer limbs together with the foil/wrap into a suitable textile glove or sock.
7. Wait for at least 10-20min, than remove all the solid paraffin with the foil/wrap from the customer limbs.
8. For the last step apply suitable nourishing cream to the customer skin surface.

CLEANING:

Before the device cleaning always anneal it (see at **OPERATION 8. chapter**) and wait for the device cool down. It is recommended to wear gloves during the process.

Place the device into an even surfaced, stable pace. Remove the device lid than hold the container bin with both hands and pour out the lukewarm, liquid paraffin from the bin into a suitable waste container. Remove the security grit form the bottom, than wipe out all the remaining paraffin with a dry paper towel. Clean the container bin inside and outside with a lightly moist solvent-free detergent soft cloth or sponge, than wipe it dry. Clean the device remaining parts with a lightly moist soft cloth, than wipe it dry with soft paper towel. Apply solvent-free disinfectant to the bin inside, than wait for its full dry. Clean the security grid and the lid with the same method as the container bin, than wait for their full dry and place them back to their places. After the cleaning check the device correct operation.

Attention! Pay attention that the device cannot have any liquid inside in its switcher, joints or can become contacted with its power cord. At first apply the cleaning material into the cloth than start he process. Do not use solvent detergents. After the moist cleaning always wait for the device full dry and do not put it under in charge for at least 1-2min.

Clean the device and its accessories as it described above after every 3-4 customer use or if it is requires more frequently.

STORAGE:

After the device annealing (see at **OPERATION 8. chapter**), wait for its full cool down. Wind the power cord loosely together while pay attention not to break it. Store the device and its accessories in a dry place, far from radiant heat in clean state. Before the device use always check device and its accessories just state.

SAFETY CAUTIONS:

1. Only for indoor use, between 0-40°C [32-104°F]!
2. Before the device operation always make sure the device and its accessories just state.
3. Before every customer use always check the paraffin correct temperature and always make sure of the customer proper skin and nail health.
4. Use/store the device only in stable, even surfaced places. Do not put the device into places where it can be knocked down or may fall off.
5. The device cannot be left behind without supervision when it is turned on.
6. The device or its accessories cannot become contact with liquids.
7. Do not ever touch the device- or its accessories with wet/moist hands.
8. Do not ever operate the device if any parts of it are damaged or had any kind of accident or fell into water! Take the device into the place of purchase for repair and seek for professional help.
9. If you experience any unusual behavior e.g.: heat raise, smell etc. during in operation, stop the device use and look for the place of purchase and ask for professional help.
10. Only authorized personals can repair the device- or its accessories.
11. The device cannot have any irrelevant objects in its openings, joints or socket.
12. Use/store the device in a dry place far from radiant heat, in a clean environment. Avoid moist/wet and contaminated places.
13. The device can have electric charges in it even if it is turned off. After the device use is finished, always anneal it according to the **OPERATION 8. chapter**.

For more information about the device, visit our website: <http://www.crystalnails.com> or look for the place of purchase.

NOTICE!

If any case of malfunction was found or any parts of the device has to be replaced or repaired, please contact with to the dealer where the unit was purchased!

ELITE COSMETIX LTD., Jozsef Krt. 44., H-1085 Budapest, Hungary