

PARAFFIN SPA

' DIGITAL PARAFFIN MACHINE '

MANUAL GUIDE

BEFORE THE DEVICE USE READ ALL THE SAFETY INSTRUCTIONS WITH ATTENTION. KEEP THIS MANUAL GUIDE SAFE FOR FUTURE REFERENCE.

INTRODUCTION:

The PARAFFIN SPA MACHINE is used for the solid paraffin melting and heating for the professional hand- & feet care process.

SPECIFICATION:

Input: AC 220-240V; 50Hz
Amperage: 1.5A
Weight: 1380g
Measure: 350*230*160mm

OPERATION

Before the device use always check device and its accessories just state.

1. Unpack the device and its accessories from the packaging, than select and even surfaced, stable place for the device use.
2. Lift the lid than take out the accessories from the container bin, than wipe it out with a soft cloth.
3. Place back the safety grid into the bin bottom, than place in the necessary amount paraffin into the container bin. Pay attention not to exceed the max. 2.5 Liter amount (2500ml). It is recommended to add the paraffin's in portions to the bin.
4. Connect the device power cord into the outlet. The device digital display will turn on and it will indicate the max. 80°C temperature.
5. Place back the lid, than set the desired temperature with the heat control buttons on the digital display sides (▲ ▼). With one press on the heat control buttons (▲ ▼) ±1°C difference can be achieved. With a longer press a fast scroll can be achieved.
6. For the solid paraffin melting, it is recommended to start the device operation on max. 80°C than after 4-5min. set back the temperature to 65°C degree till the paraffin 70-80% is melted. After the paraffin 70-80% is melted, set the temperature to app. 40°C degree for customer use. See more below at the **USAGE** chapter.
7. For the operation start, press the „START” button on the middle.
8. After the device use is finished press the „START” button on the middle, than remove the device power cord from the outlet.

ATTENTION

The max. 80°C temperature is not suitable for customer use. It is only used to start the paraffin melting process. It is recommended to start the melting process at 80°C than after 4-5min. set back the temperature to 65°C degree with the heat control buttons help (▲ ▼), till the paraffin 70-80% is melted. After the paraffin 70-80% is melted, set the temperature to app. 40°C degree for customer use. **Notice:** the melting time and temperature can be different with the different type of paraffin's. If you notice the paraffin top is started to solidify or “skinning” raise the temperature with a few degree and if it is necessary stir the paraffin in the bin.

USAGE (on customer):

1. Before every customer use always check the paraffin correct temperature and always make sure of the customer proper skin and nail health.
2. Remove all accessories from the customer hand/feet, than disinfect the customer limbs.
3. Apply suitable skin scrub for the customer skin surface, than when the process finished remove all the applied material from the skin surface, than wipe it dry.
4. Apply suitable nourishing cream into the customer hand/feet, than place the customer limbs into the container bin bottom. **Attention!** Before the customer use always check the paraffin correct temperature.
5. Take out the customer hand/feet from the paraffin, than wait for at least 10sec till the paraffin solidifies on the skin.
6. Repeat the previous step a few times (**USAGE 4. chapter**) than place the customer limbs separately into a waterproof foil or wrap. If it is necessary place the customer limbs together with the foil/wrap into a suitable textile glove or sock.
7. Wait for at least 10-20min, than remove all the solid paraffin with the foil/wrap from the customer limbs.
8. For the last step apply suitable nourishing cream to the customer skin surface.

CLEANING:

Before the device cleaning always anneal it (see at **OPERATION 8. chapter**) and wait for the device cool down.
It is recommended to wear gloves during the process.

Place the device into an even surfaced, stable pace. Remove the device lid than hold the container bin with both hands and pour out the lukewarm, liquid paraffin from the bin into a suitable waste container. Remove the security grit form the bottom, than wipe out all the remaining paraffin with a dry paper towel. Clean the container bin inside and outside with a lightly moist solvent-free detergent soft cloth or sponge, than wipe it dry. Clean the device remaining parts with a lightly moist soft cloth, than wipe it dry with soft paper towel. Apply solvent-free disinfectant to the bin inside, than wait for its full dry. Clean the security grid and the lid with the same method as the container bin, than wait for their full dry and place them back to their places. After the cleaning check the device correct operation.

Attention! Pay attention that the device cannot have any liquid inside in its switcher, joints or can become contacted with its power cord. At first apply the cleaning material into the cloth than start he process. Do not use solvent detergents. After the moist cleaning always wait for the device full dry and do not put it under in charge for at least 1-2min.

Clean the device and its accessories as it described above after every 3-4 customer use or if it requires more frequently.

STORAGE:

After the device annealing (see at **OPERATION 8. chapter**), wait for its full cool down. Wind the power cord loosely together while pay attention not to break it. Store the device and its accessories in a dry place, far from radiant heat in clean state.
Before the device use always check device and its accessories just state.

SAFETY CAUTIONS:

1. Only for indoor use, between 0~40°C [32~104°F]!
2. Before the device operation always make sure the device and its accessories just state.
3. Before every customer use always check the paraffin correct temperature and always make sure of the customer proper skin and nail health.
4. Use/store the device only in stable, even surfaced places. Do not put the device into places where it can be knocked down or may fall off.
5. The device cannot be left behind without supervision when it is turned on.
6. The device or its accessories cannot become contact with liquids.
7. Do not ever touch the device- or its accessories with wet/moist hands.
8. Do not ever operate the device if any parts of it are damaged or had any kind of accident or fell into water! Take the device into the place of purchase for repair and seek for professional help.
9. If you experience any unusual behavior e.g.: heat raise, smell etc. during in operation, stop the device use and look for the place of purchase and ask for professional help.
10. Only authorized personals can repair the device- or its accessories.
11. The device cannot have any irrelevant objects in its openings, joints or socket.
12. Use/store the device in a dry place far from radiant heat, in a clean environment. Avoid moist/wet and contaminated places.
13. The device can have electric charges in it even if it is turned off. After the device use is finished, always anneal it according to the **OPERATION 8. chapter**.

For more information about the device, visit our website: <http://www.crystalnails.com> or look for the place of purchase.

NOTICE!

If any case of malfunction was found or any parts of the device has to be replaced or repaired, please contact with to the dealer where the unit was purchased!

ELITE COSMETIX LTD.; Jozsef Krt. 44., H-1085 Budapest, Hungary

[EN] PARAFFIN HEATER [HU] PARAFFIN MELEGÍTŐ [RO] INCALZITOR DE PARAFINA [DE] PARAFFIN-WÄRMER [FR] PARAFFINE CHAUFFE
[IT] MACCHINA PER PARAFFINA [ES] CALENTADOR DE PARAFINA