

# ATTRACTIVE DUST COLLECTOR

## - MANUAL GUIDE -

PLEASE READ ALL THE SAFETY INSTRUCTIONS THOUGHTFULLY BEFORE THE DEVICE OPERATION.  
KEEP THIS MANUAL GUIDE SAFE FOR FUTURE REFERENCE.

### Product introduction:

The ATTRACTIVE DUST COLLECTOR are used for the emerging dust/contaminations continues absorbing from the nail sculpting - and the manicure procedure.

### Specifications

#### ATTRACTIVE DUST COLLECTOR

Voltage (V): 220-240V

Amperage (A): 1.5A

Frequency (Hz): 50Hz

Weight (g): 1730g

Measure (mm): 315\*295\*100mm

### OPERATION

**ATTENTION!** Before the machine operation, check the device and its accessories just state.

1. Unpack the device from the packaging.
2. Choose a suitable place for the device usage.
3. After the device setting plug the power cord into the outlet.
4. Turn on the device with the switcher I/O (ON/OFF) on the side of the machine. The device will run on continuous mode.
5. Place the hand above the exhaust vent opening, than you can start working with it.

**ATTENTION!** DO NOT allow any kind of irrelevant object to the exhaust vent opening (nails, nail form, file...etc.)!

6. After the work is finished with the device, turn it off with the I/O (ON/OFF) switcher at the side of the machine than pull out the power cord from the outlet.

### CLEANING AND STORAGE

**ATTENTION!** Before cleaning always anneal the device (turn off the machine, than remove the power cord from the AC outlet), as well as wait for the machine full stop.

DO NOT disassemble the device!! For the ATTRACTIVE DUST COLLECTOR cleaning/maintenance use compressed air, brush and a non synthetic soft towel.

**DEVICE:** Put the device into an even surfaced stable place (it is recommended to put a cloth under the device), than move off the dust bag with care (see **DUST BAG**). Turn the device upside down than clean the external panel and the fan blades through the security grid with the brush and compressed air. For the hard to reach parts (switcher, socket, joints) use compressed air, than wipe out the machine with a soft, dry cloth. Turn back the device to its original position, than clean the device external panel along with the exhaust vent with the fan blades as well. Use brush and compressed air for their cleaning. Wipe out the machine with a soft, dry cloth again. If the cleaning finished put back the fully dry dust bag back to the exhaust vent, after that place back the device to its place.

**NOTICE:** If it necessary the device external panel can be cleaned with a lightly moist, soft cloth, but pay attention that the device CANNOT have any liquid inside in it or in its switcher, openings or sockets, as well as CANNOT be contacted with the device power cord. After the moist cleaning, always wait for the device full dry as well as do not put it under it charge at least 1-2 min.! DO NOT use solvent detergents!

**POWER CORD:** Pull out the power cord from the outlet, than clean it with brush and compressed air. Pay high priority to the joints.

In case of average frequency use, clean the device and its parts according to the described above at least once a week.

**DUST BAG:** Put the device to an even surfaced stable place (it is recommended to put a cloth under the device), than move off the dust bag with care. Turn out the dust bag than empty the accumulated dust/contaminations from it. Clean the emptied dust bag with careful hand wash, in lukewarm lightly detergent water. After the cleaning wait for the dust bag full dry. Only after the full dry place back the dust bag to the exhaust vent.

The emptying itself NOT enough for the dust bag cleaning!  
After each of the emptying, always wash out the dust bag according to the described above. Use the device only with a full dry dust bag!

If you notice lower capacity during in use or the device has less downdraught, check the dust bag saturation and if it is reasonable clean it according to the described above (see **DUST BAG**).

In case of average frequency use, check the dust bag saturation at least once a week and if it is reasonable clean it according to the described above (see **DUST BAG**).

For future information about the device cleaning/maintenance visit our website: <http://www.nails.tv> or if it requires look for the place of purchase.

**STORAGE:** Store the device always in a dry place, far from radiant heat in a clean state.

Before the device installation always check the device and its parts for any kind of defect.

### SAFETY CAUTIONS

1. Only for indoor use, between 0-40°C (32-104°F)!
2. The machine cannot be left behind, without supervision when it is turned on.
3. Do not put the machine onto places where it can be knocked down, or may fall off. Use the device only in stable, even surfaced places!
4. The machine CANNOT have any liquid inside in it or in its switcher, openings or sockets, as well as CANNOT be contacted with the device power cord.
7. Do not ever touch the machine or its parts with moist/wet hand!
5. DO NOT ever activate the machine if its power cord or socket is damaged, as well as if it had any kind of accident or it fell into the water!  
Take the device to the place of purchase for examination and repair.
6. DO NOT allow any kind of irrelevant object to the device openings, socket as well as to the exhaust vent opening (nails, nail form, file...etc.)!
7. Use/store the device only in dry places and keep it far from radiant heat! Avoid damp, wet places!
8. The electric parts of the machine may have electric pressures on them even when the device is turned off.
9. At the end of the device use, always anneal the machine (turn off the device, than remove the power cord from the AC outlet).

For more information about the device, visit our website: <http://www.crystalnails.com> or look for the place of purchase.

### NOTICE!

If any case of malfunction was found or any parts of the machine has to be replaced or repaired, please contact with to the dealer where the unit was purchased!

**Importer:** Elite Cosmetics LTD., Jozsef Krt. 44., H-1085 Budapest, Hungary

[ EN ] ATTRACTIVE NAIL DUST COLLECTOR [ HU ] ATTRACTIVE PORELSZÍVÓ [ RO ] ASPIRATOR DE PRAF ATTRACTIVE [ DE ] ATTRACTIVE NAGEL STAUBABSAUGER  
[ FR ] ASPIRATEUR À POUSSIÈRE ATTRACTIVE [ IT ] ASPIRATORE PER UNGHIE ATTRACTIVE [ ES ] ASPIRADOR DE POLVO ATTRACTIVE